

WALL CONTROL PANEL



Display Controls on top left and bottom right (**yellow box**). Sources on right side (**blue box**). Audio Controls on the bottom left (**purple**).

- Press the Display **On** button. *Wait* for the display to turn on.
- Press the source button you wish to use.
 - **Room PC:** Allows teacher to use the PC built into the mobile cart
 - **HDMI:** HDMI cord attached to the panel next to the controller
 - **ShareLink:** Wireless display gateway: Connect your notebook or mobile device wirelessly.
 - **Mute:** Audio/video mute button, press once to mute the video on the projector and the audio from the speakers, press again to unmute
- When finished, press the Display **Off** button.

LAPTOP CONNECTIONS



The Laptop HDMI connection is on the right side (**Green box**).

The Laptop can be connected to the panel above which will be on the wall next to the control panel. Laptop cable will be provided.