


TSC 1005 ROOM AV CONTROLS



Display Controls on top left (yellow box). Sources on right column (blue box).
Audio controls on bottom left (purple box).

- Press the Display **On** button. *Wait* for the display to turn on.
- Press the source button you wish to use:
 - **Laptop:** HDMI or VGA cord on the laptop connection panel.
 - **ShareLink:** Wireless display gateway: Connect your notebook or mobile device wirelessly.
 - **Doc Cam:** Document camera located in the ceiling above the carpet X.
- When finished, press the Display **Off** button.

LAPTOP CONNECTIONS



The HDMI connection is on the left (green box). The VGA and audio connection are on the right (pink box).

Laptop connections are connected to the panel above.
Panel is on the wall down and to the right of the control panel. Laptop cables are provided.



TSC 1005 DOCUMENT CAMERA

DOCUMENT CAMERA LOCATION



The black **X** on the carpet is the location of the camera.

DOCUMENT CAMERA REMOTE



The document camera can be controlled from the remote.

Use the **TELE** button to zoom in, and the **WIDE** button to zoom out (**yellow boxes**).

