



TOUCH SCREEN CONTROL PANEL



Display Controls on left (**yellow box**). Sources on top (**blue box**). Audio Controls on the right (**purple**).

- Press the Display **On** button. *Wait* for the display to turn on.
- Press the source button you wish to use.
 - **PC**: PC is below the keyboard tray
 - **Laptop**: HDMI or VGA cord in the cable cubby
 - **Doc Cam**: Typically on the top of the podium. Controls will appear on the touchpanel OR you can use the controls on the top of the doc cam
- When finished, press the Projector **Power** button and log out of the PC if you used it.

LAPTOP CONNECTIONS



Laptop connections are in the cable cubby (Metal box in the podium)
If the cable cubby lid is closed, it looks like a metal plate - lift to open it.